

## How to Assemble Your Blind Base Corner Cabinets

Before you start to assemble your cabinet, please make sure that all of the following parts are included in the carton. In case of any shortage, please contact the dealer and request the delivery of the missing part.

**A** – Door Faceframe (1)

**B** – Side Panels (2)

**C** – Shelf (1)

**D** – Bottom (1)

**E** – Back Panel (1)

**F** – Large Face Board (1)

**G** – Small Face Board (1)

**H** – Toe Kick (1)

**L** – Hardware Bag (1); Corner Braces – 4, Medium Screw – 8, Drawer Slide Holders – 2, Shelf Holders – 4, Largest Screw – 4, Smallest Screw – 24, Right Angle Brackets – 4

**K** – Drawer Slides (2)

**M** – Drawer Parts; **a** – Front (1), **b** – Side w/ Slides (2), **c** - Bottom(1), **d** – Back(1)

Please use the following steps to begin assembly:

1. Take out all of the parts from the carton and carefully lay the Door Faceframe (A) with finished side downwards onto a soft and flat surface so that it will not be scratched.
2. Two Side Panels (B) are to be positioned into the grooves on Faceframe (A). Align the metal connectors and press downward until the half sections of the metal connectors on the Door Faceframe (A) fit properly into the mates on the Side Panels (B). For best results, place a screw into the metal sliders after locked into place.
3. Insert Bottom (D) into the grooves of Side Panels (B) and Faceframe (A).
4. Position Back Panel (E) onto Side Panels (B) so that the bottom channel fits over Bottom (D). Place Toe Kick (H) onto Side Panels (B) at front base of cabinet. Make sure all is flush.
5. Stand the cabinet upright and attach the 4 Corner Braces in each corner of the cabinet using 8 of the small screws. The 4 longest screws are for use later to tie the countertop to the base cabinet through the corner braces.