

To increase the strength of the cabinet, “L” brackets have been added to secure the face frame to the side panels. Use the following instruction for installation:

- Step 1. After assembling the wall cabinet, place the cabinet face down on a clean, dry work cloth.
- Step 2. Place the “L” brackets into the corner of the face frame and the side panels as shown below. Using a screwdriver, fasten the screws to the side panel and then to the face frame. Repeat these steps for the second “L” bracket.
- Step 3. Turn the cabinet around and install the other two brackets to the bottom end.

