






# ASSEMBLY INSTRUCTIONS MICROWAVE OVEN CABINET(MC3018)

## CABINET PARTS LIST

A-Annex(2) B-End Panels(2) D-Bottom Panel & Top Panel E-Back Panel

## HARDWARE PARTS LIST

None



LINK